

# MAKEUP AIR

## WHEN A BALLOON LOSES AIR OR DEPRESSURIZES, IT GETS SMALLER (AND MAKES A FUNNY SOUND), BUT HOUSES DON'T ROLL LIKE THAT

#### BY JONATHAN SMEGAL

A skeup air is outside air that replaces air exhausted from inside the building. In most houses, there are several appliances that push or pull air out of the house, including clothes dryers, bathroom fans, fireplaces and kitchen range hoods. When even one of those appliances is operating, it depressurizes the interior. Nature abhors a vacuum, so to restore the pressure balance, outside air is sucked into the house.

Unless airways are deliberately provided for that incoming air, it will flow in through the path of least resistance, such as gaps around windows and doors, between framing and the foundation, and at other leaky building components. If the rate at which air is exhausted is high enough, the suction created can be strong enough to reverse the draft in a water heater vent, furnace chimney or fireplace, drawing noxious fumes and deadly carbon monoxide into the house.

#### Why It Matters

Makeup air is more of an issue these days for two main reasons: (1) houses are getting significantly tighter and (2) range hood fans have been getting significantly more powerful to accommodate a growing trend toward putting large commercial-style ranges in residential kitchens. Large range hoods can draw out air at the rate of 1200 CFM or more roughly a small roomful of air every 60 seconds which by itself could be enough to reverse the draft in a furnace or water-heater flue.

AIR CURRENTS ALSO CAN BE CREATED NATURALLY. FOR MORE INFORMATION, GO TO PROTRADECRAFT. COM, AND SEARCH FOR "STACK EFFECT." But big range hoods aren't the only problem. Several smaller fans running at once—for example, a dryer, small range hood, and bath fan—can cause the same level of depressurization. So can a big, open fireplace, in fact, I know of a case in which a roaring fire in a fireplace in a tight house reversed the draft in the secondary flue and filled the basement with noxious fumes.

In addition to the safety concerns, the downside

of depressurization includes a big energy penalty from exhausting air that you've spent good money to heat or cool, while at the same time drawing in outside air that will cost more money to heat or cool once it gets inside. And unless all this air flow is controlled, it creates drafts, which make people uncomfortable. If the incoming air is humid, it can bring unwanted moisture into the house. In a cooling climate, that moisture can condense against the back side of cool, air-conditioned walls and cause concealed mold and rot.

Air leaking into the house through an unsealed crawl space also can contain water vapor as well as mold spores, particulate matter and potentially harmful gases. I know of an instance involving a commercial restaurant in which the very powerful kitchen exhaust fans were operating, but the makeup air units weren't. The depressurization was so powerful that sewer gas bubbled up through the traps in the toilets. The odor chased a lot of unhappy customers out of the dining room.

#### How To Do It Right

Bubbling toilets aren't likely to occur in residential construction, but depressurization is still a potential problem. In the past when houses were much leakier, this phenomenon was not as serious an issue because air would just leak in through nearby windows and doors, and even through walls, to make up the pressure difference caused by the exhausted air. People may have been uncomfortable, but at the least the house didn't fill with noxious fumes. But with tight houses, we can't rely on air leaks to solve our problem. We have to plan for and provide the solution.

One place to begin is with the code. To paraphrase Section 1503.4 of the 2012 IRC, an exhaust hood that can draw more than 400 CFM must be supplied with makeup air at a rate that roughly balances the outflow and inflow. Plus, the exhaust and makeup



Editor's Note: Examples of makeup air solutions include: 1 The Residential Makeup Air System (RMAS) from CCB Innovations includes an air flow sensor mounted inside a standard duct coupling, which signals a motorized damper in a second coupling to open when air is flowing and close when air flow stops. 2 Broan's direct-wire, synchronized Automatic Make-Up Air Dampers work with specific company range hoods, operate automatically when the range hood is activated, and are compatible with whole-house ventilation systems. 3 The automated Makeup Air System (MUAS) from Fantech includes an intake hood, shut-off damper, filter, fan, duct silencer, and optional heater; available models handle air flow up to 2,000 CFM.

air systems have to be connected. Typically wha happens is, as soon as you turn on the range ho it will send a signal to a damper in the makeup a duct, which will open to allow air to flow in. Wh the range hood shuts off, the damper will close, blocking infiltration of unconditioned air.

Contractors who think this is an overly complete and expensive solution often note that the simp makeup air strategy is to open the window next the range hood. This will work, but only in certar very specific climate zones where you don't need to heat or cool incoming air at any time of year. Codewise, however, it's a manual solution, and r an automatic connection.

More typically, the solution involves ductwork In a forced air heating system, outdoor air can be brought into an air handler on the return side then distributed through the ductwork. In milde climates, the makeup air may not need to be conditioned directly because it is tempered as it

### **PROTRADECRAFT.COM**

at	moves through the ductwork. But in cold or hot
od,	climates, it may be necessary to heat or cool the
air	incoming air directly to prevent comfort issues.
nen	Range hood manufacturers are starting to provide
	interlocked makeup air damper kits, and several
	third-party "universal solutions" also are available.
ex	Both types of systems typically consist of a short
olest	length of ductwork with a motorized damper inside
t to	that operates by means of a pressure switch located
ain,	in the exhaust duct. Some models are "interlocked"
ed	with "slave" dampers so that the exhaust and intake
	are synchronized, and some also are designed to
not	work with whole-house ventilation systems.
	· · · · · ·
۲.	Jonathan Smegal is senior project manager at RDH
	Building Science Laboratories in Waterloo, Ontario,
e,	Canada. This article was adapted from "Make-Up Air:
er	7 Minutes of BS," a building science podcast series at
	ProTradeCraft.com. You also can subscribe to the podcast
t	at iTunes, SoundCloud, or Google Play.
	at marico, obariaciona, or coogle flay.